

ASSEMBLY INSTRUCTION

Bristol Dining Chair

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which have come loose inside the carton during shipment. Identity and count all parts and compare with the part list below. Place all wooden furniture parts on a clean and flat soft surface, such as carpet or rug to prevent from being scratched.

LIST OF PARTS

No	Description	Qty
1	Chair Back	1 PC
2	Box Seat Frame	1 PC
3	Chair Front Leg (L&R)	2 PCS
4	Chair Seat	1 PC
5	Stretcher	2 PCS

HARDWARE LIST

No	Description	Qty
A	JCBC BOLT (LONG)	4 PCS
B	JCBC BOLT (MEDIUM)	4 PCS
C	JCBC BOLT (SHORT)	2 PCS
D	Flat Washer	10 PCS
E	Spring Washer	10 PCS
F	Wood Screw (Short)	4 PCS
G	Wood Screw (Long)	4 PCS
H	Allen Key	1 PC

WARNING

- This Chair not suitable for Standing On
- Do Not over Tighten the bolts and screw

