


TYLER 2652M-Montážny návod




Ax4 M6X20
Bx8 M6X25
Cx1
M6

(1) X1	(2X1	(3) X1	(4) X1	
				
(5) X1	(6) X1	(7) X1	(8) X5	(9) X8
				



Ax4 M6X20
Bx8 M6X25
Cx1
M6

(1) X1	(2) X1	(3) X1		(4) X1
				
(5) X1	(6) X1	(7) X1	(8) X5	(9) X8
				

